

Table of Contents	Page
1. Safety Terms and Symbols	1
2. Introduction	5
3. Preliminary Notes	6
4. Panel Description	7
5. Operation Method	10
6. Specifications	13
7. Maintenance	17
7-1. Cleaning.....	17
7-2 .Troubleshooting.....	17
8. Interchangeable Parts	18


UNITED KINGDOM ONLY

Lead/appliance must only be wired by competent persons


THIS APPLIANCE MUST BE EARTHED

NOTE: The wires in this lead are coloured in accordance with the following code:

Yellow: Earth
Neutral
Live(Phase)



If the wires in main leads may not correspond with the wiring identified in your plug/appliance, proceed as follows:

If the wire which is coloured Green & Yellow must be connected to the terminal marked with the letter E or by the earth symbol  Green or Green & Yellow.

If the wire which is coloured Blue must be connected to the terminal marked with the letter N or coloured Blue or Black.

If the wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.

Consult the instructions provided with the equipment or the supplier.

The appliance should be protected by a suitably rated and type of mains fuse: refer to the rating information on the label and/or user instructions for details. As a guide, cable of 1.5mm² should be protected by a 3A or 5A fuse. Larger conductors

ity

ty 236, Taiwan
D.
, China.

at in the Council Directive
ating to Electromagnetic
Low Voltage Equipment
ibility and Low Voltage

pl and laboratory use
charge 1995
ity 1995
transients 1995
1995
ptibility 1996
/ Magnetic field 1993
errupts 1994

ended by 93/68/EEC

ary Notes

unding terminal:

the chassis ground terminal is connected to the earth
 erting the power plug into the main supply.

put voltage:

ter may be damaged if any input voltage exceeding
 ed voltage is applied to it. The specified voltage is
 by adding the peak value of the input signal and the
 ed DC voltage: 300 V for the 300 μ V ranges, and
 he 3 V to 100 V ranges.


leads:

measured signal level is low (i.e. 300 μ V) or the
 signal source impedance is high, the input line is
 to external noise. To resist the noise, shielded wires
 al cable should be used depending on the noise

voltmeter adopts a special extended scale which has
 ange larger than the conventional full scale.

Conventional	Extended
0 to 1.0	0 to 1.12
0 to 3.1 (3.2)	0 to 3.5
-20 to 0 dB	-20 to +1 dB
-20 to +2 dBm	-20 to +3.2 dBm

he term "full scale" considers '1.0' on the 0 - 1.12
 e rated value. The red ▼ mark is setting at '1.0' on
 ost scale.



set,
ent

is

at a
re,

een

two
bel.

to
:

Decibel is originally the ratio of power as explained above. However, the logarithm of the ratio of other values (ratio of voltage or current) can also be called "decibel".

For example, If the input voltage of an amplifier is 10 mV and output voltage is 10 V, the degree of amplification could be $10 \text{ V} / 10 \text{ mV} = 1000$ times. This is also expressed in dB as follows:

$$\text{Degree of amplification} = 20 \log (10 \text{ V} / 10 \text{ mV}) = 60 \text{ dB}$$

dBm

"dBm" is the abbreviation of dB (mW). This decibel value expressed the power ratio with respect to 1 mW. Normally, "dBm" implies the condition where the power exists in impedance of 600 Ω .

Therefore, "0 dBm" can be signified as the following:

$$0 \text{ dBm} = 1 \text{ mW or } 0.775 \text{ V or } 1.291 \text{ mA}$$

The power or voltage levels are determined by adding up the scale readings and the selected RANGE settings.

Example:

Scale	RANGE	Level
-------	-------	-------

$$(-1 \text{ dB}) + (+20 \text{ dB}) = +19 \text{ dB}$$

$$(+2 \text{ dBm}) + (+10 \text{ dBm}) = +12 \text{ dBm}$$

4. The dB and dBm scales of the indicating meter are as stated the following:

Range setting	dB	dBm
+40	+20 to +41	+20 to +43
+30	+10 to +31	+10 to +33
+20	0 to +21	0 to +23
+10	-10 to +11	-10 to +13
0	-20 to +1	-20 to +3
-10	-30 to -9	-30 to -7
-20	-40 to -19	-40 to -17
-30	-50 to -29	-50 to -27
-40	-60 to -39	-60 to -37
-50	-70 to -49	-70 to -47
-60	-80 to -59	-80 to -57
-70	-90 to -69	-90 to -67

s (Cont.)

1. Within $\pm 3\%$ of full scale at 1 kHz (signal input only, without any interference).
2. Only pure signal input at 100kHz, the double isolation wire is used for the signal input and the CORE is used for the purpose of isolation.
Depend on the IEC-1000-4-3:
Testing frequency range: 80 MHz~1GHz,
Testing level: 3 V/m
Amplitude modulation: AM 80%, at 1 kHz
 - (a) the voltage accuracy is $\pm 10\%$ (full scale) normally.
 - (b) the voltage accuracy is $\pm 15\%$ (full scale) at the range of 630 ~ 640 MHz testing frequency.

Approximately $1\text{ M}\Omega$

$\leq 50\text{ pF}$

300 V (at $300\text{ }\mu\text{V} \sim 1\text{ V}$ ranges)
500 V (at $3\text{ V} \sim 100\text{ V}$ ranges)

$\leq 0.1\ \Omega$

$0.1\text{ V}_{\text{rms}} \pm 10\%$ for each range of 1 kHz
(at full scale without load)

Table 1: Specifications (Cont.)

AC Output Frequency Response	10 Hz to 1 MHz, $\leq \pm 3\%$ (reference: 1 kHz. without load)
Stability against Line Voltage Fluctuation	Indication change with respect to line voltage fluctuation of $\pm 10\%$; is within $\pm 0.5\%$ of full scale.
AC Power Requirement	115 (97~132) Vac / 230 (195~250) Vac, 50/60 Hz
AC Power Consumption	10VA or 4.0 Watts, Maximum
Fuse Replacement for 115 Vac selected	T type, 0.2 A, 250Vac
Fuse Replacement for 230 Vac selected	T type, 0.1 A, 250Vac
Operation Environment	Indoor user, Altitude up to 2000M Installation Category II Pollution Degree 2 Operating Temperature : +0° C to +40°C, < 80% relative humidity Storage Temperature : -10° C to +70°C, < 70% relative humidity
Dimensions	130 (W) x 210 (H) x 295 (D) mm
Weight	Approximately 2.7 kg

* : Between the input common and chassis.

7. Maintenance

This section includes the basic maintenance information for GVT-417B.

7-1. Cleaning

To clear GVT-417B, use soft cloth dampened in a solution of mild detergent and water. Do not spray cleaner directly onto the instrument, since it may leak into the cabinet and cause damage.

Do not use chemicals containing benzene, benzene, xylene, acetone, toluene, or similar solvents.

Do not use abrasive cleaners on any portion of this equipment.

7-2. Troubleshooting

Troubleshooting the GVT-417B is limited to checking the input power fuse. If you have other operational difficulties with your GVT-417B, contact your Good-Will representative for assistance.



WARNING. To avoid electrical shock, the power cord protective grounding conductor must be connected to ground.



WARNING. To continued fire protection. Replace fuse with the specified type and rating, and disconnect the power cord before replacing fuse.

8. Interchangeable Parts

Interchangeable parts can be ordered from your authorized GoodWill dealer directly.

Accessories

The items are shipped with the GVT-417B as following:

Table 2: Accessories

Accessory	Good Will Part Number
Test Leads GTL-101 x 1 (for GVT-417B)	1100-TL101U0
User Manual	82VT-417B0MC